

ECB Protoboard III 1606 Updates

04-Oct-2017

(mandatory, 6 wires, no cutting)

1. A7: connect U5.2 to U2.3
2. A6: connect U5.4 to U2.5
3. A5: connect U5.6 to U2.7
4. A4: connect U5.8 to U2.9
5. A3: connect U5.11 to U2.12
6. A2: connect U5.13 to U2.14

Schematic remains current, but A7..A2 leaving the bus are not connected to A7..A2 on K1..K6. This is a Kicad netlist bug, IMHO.