



hardware handshake
utilize interrupt inputs
connect CF interrupt to one of inputs

CB030
A MC68030 SBC in 100mm x 100mm
Jan 2020
©2020 H. Shen

Change log
Rename CB030 as inspired by Cecil B.

- 5 modes of operations
1. CPLD checkout
2. Serial bootstrap
3. Program EPROM
4. EPROM boot
5. Bring up CP/M & OS

Use R/V instead
Bring in DTRACK

Bootstrap Mode

JUMP3BLK-A

2nd Bank

in-situ

RT is like JAK