



**P1 ZBUS-40**

R15	1	A15
R14	2	A14
R13	3	A13
R12	4	A12
R11	5	A11
R10	6	A10
R9	7	A9
R8	8	A8
R7	9	A7
R6	10	A6
R5	11	A5
R4	12	A4
R3	13	A3
R2	14	A2
R1	15	A1
R0	16	A0
	17	GND
	18	VCC
	19	GND
	20	M1
	21	RESET
	22	CLK
	23	INT
	24	WREQ
	25	WR
	26	RD
	27	IORQ
	28	D0
	29	D1
	30	D2
	31	D3
	32	D4
	33	D5
	34	D6
	35	D7
	36	TX
	37	SPARE1
	38	SPARE2
	39	SPARE3
	40	SPARE4

Add 14 DIP for 512K RAM  
Default configuration is W27512 & A86C1024

