



No need to populate MCP130 and RESET button
Unless board is standalone